

(1) Interrupt pin goes high during execution of current instruction

I_{curr}
 I_{next}

(2) Control passes to handler after current instruction finishes

(3) Interrupt handler runs

(4) Handler returns to next instruction

